



evolution
evolutionpowertools.com

Service Parts List	V4	R255DWS-T	ALL PARTS
255mm Drywall Sander		UK 220-240V	078-0010

Item	Description	Part No	Qty
A1	LEFT MAIN HANDLE	078-0401	1
A2	LEFT STENT	078-0402	1
A3	CABLE STRAIN RELIEF	078-0403	1
A4	WASHER 14 x 4 x 1	F-W-4-1-ST-BO	1
A5	SCREW THREAD FORMING M4 X 18	F-TFPX-M4-18-ST-BO	1
A6	SCREW THREAD FORMING M4 X 14	F-TFPX-M4-14-ST-BO	2
A7	CABLE RESTRAINT SADDLE	078-0404	1
A8	DOUBLE CONDUCTOR HOSE 460MM	078-0405	1
A9	SCREW THREAD FORMING M4 X 25	F-TFPX-M4-25-ST-BO	1
A10	HOOP	078-0406	1
A12	DUAL CHANNEL	078-0407	1
A13	FRONT DOUBLE CHANNEL ALUMINUM TUBE	078-0408	1
A14	FRONT HINGE SLEEVE	078-0409	1
A15	CORE PULLING WILLOW NAIL	078-0410	2
A16	FOAM PAD	078-0411	1
A17	REAR HINGE SLEEVE	078-0412	1
A18	ROUND PIN 5 X 34	078-0413	1
A19	PCB (UK/EU 230V)	078-0442	1
A20	TWO PIN CAPACITOR (UK/EU 230V)	078-0415	1
A21	SMALL SQUARE SWITCH	078-0416	1
A22	SWITCH PITTER	078-0417	1
A23	SWITCH BUTTON	078-0418	1
A24	ROUND PIN 1.5 X 11.8	078-0419	1
A25	TRIGGER LOCK	078-0420	1
A26	ROUND PIN 5 X 28	078-0421	1
A27	TWO-CORE FLAT WIRE	078-0422	2
A28	MASTER HANDLE ASSEMBLY	078-0423	1
A29	MAIN HANDLE SEAL SLEEVE	078-0424	1
A30	SEAL SLEEVE INSERT	078-0425	1
A31	REAR DOUBLE CHANNEL ALUMINUM TUBE	078-0426	1
A32	HEADLESS THREAD	078-0427	2
A33	ROUND PIN 5 X 30	078-0428	1
A34	ROUND PIN 5 X 16.8	078-0429	1
A35	BRACE	078-0430	1
A36	LOCKING LEVER	078-0431	1
A37	DOUBLE SIDED SHEATH	078-0432	2
A38	SMALL SWITCH	078-0433	1
A39	LED	078-0434	1
A40	LED LENS	078-0435	1
A41	RIGHT STENT	078-0436	1
A42	SCREW THREAD FORMING M4 X 16	F-TFPX-M4-16-ST-BO	20
A43	FRONT HINGE SLEEVE SIDE PANEL	078-0437	1
A44	LEFT SIDE HANDLE	078-0438	1
A45	POWER CABLE & PLUG 230V 3M (UK)	078-0439	1
A46	CABLE SLEEVE	078-0442	1
A47	RIGHT MAIN HANDLE	078-0443	1
A49	END CONNECTOR	078-0444	1
A50	LOCK LOOP	078-0445	1
A51	SECONDARY HANDLE SEAL SLEEVE	078-0446	1
A52	FOAM GASKET	078-0447	1
A53	SINGLE CHANNEL ALUMINUM TUBE 27.6 X 1 X 550	078-0448	1
A54	EXTENDED ROD GUIDE SLEEVE	078-0449	1
A55	RIGHT SIDE HANDLE	078-0450	1
A56	FRONT HINGE SLEEVE REAR SIDE PANEL	078-0451	1
A57	SCREW THREAD FORMING M4 X 16	F-TFPX-M4-16-ST-BO	2
B1	SCREW CROSS HEAD TAPPING M4 X 16	F-TFPX-M4-16-ST-BO	4
B2	UPPER CAP ASSEMBLY	078-0452	1
B3	UPPER END CAP	078-0453	1
B4	BEARING 62722	F-B-627-22	1
B5	BEVEL TEETH GEAR	078-0454	1
B6	SCREW PAN HEAD POZIDRIV M4 X 14	F-SHPZ-M4-14-ST-BO	2
B7	LEFT ACTIVITY SLEEVE	078-0455	1
B8	ROUND PIN 3 X 20	078-0456	1
B9	HEAD ASSEMBLY	078-0457	1

Item	Description	Part No	Qty
B10	CIRCLIP 24	F-CCEXT-24-ST-BO	1
B11	BEARING 6901	F-B-6901	1
B12	HEAD	078-0458	1
B13	RECTANGULAR RING	078-0459	1
B14	RIGHT ACTIVITY SLEEVE	078-0460	1
B15	LOCK SHAFT ASSEMBLY	078-0461	1
B16	LOCK BUCKLE SHAFT	078-0462	1
B17	SELF-LOCKING BUTTON	078-0463	1
B18	WOODRUFF KEY 3 X 3.5 X 10	078-0464	1
B19	BEVEL GEAR SHAFT	078-0465	1
B20	LEFT SUPPORT BLOCK	078-0466	1
B21	SCREW PAN HEAD POZIDRIV M4 X 8	F-SHPZ-M4-8-ST-BO	2
B22	REST SPRING M6	078-0467	1
B23	FOUR TOOTH CONNECTING SLEEVE	078-0468	1
B24	GASKET $\phi 24 \phi 17 \ 3 \times 3$	078-0469	1
B25	FOUR TOOTH SHAFT	078-0470	1
B26	LOCK PLATE	078-0471	1
B27	SCREW COUNTERSUNK HEAD POZIDRIV	F-SCHPZ-M4-12-ST-BO	4
B28	RIGHT SUPPORT BLOCK	078-0472	1
B29	CIRCLIP 4 X 0.8	F-CCINT-4-080-ST-BO	1
B30	SPRING 5.2	078-0473	1
C1	WOOL RING	078-0474	1
C2	WOOL GASKET	078-0475	1
C3	ROTOR ASSEMBLY (UK/EU 230V)	078-0476	1
C4	BEARING 6000	F-B-6000	1
C5	DUST PROOF GASKET $\phi 23.3 \times 10.2 \times 0.5$	078-0478	1
C6	ROTOR (UK/EU 230V)	078-0479	1
C7	DUST RING	078-0481	1
C8	BEARING 607 RS	F-B-607-RS	1
C9	FAN BAFFLE	078-0482	1
C10	SCREW PAN HEAD POZIDRIV M4 X 55	F-SHPZ-M4-55-ST-BO	2
C11	STATOR (UK/EU 230V)	078-0483	1
C12	CABLE STRAIN RELIEF	078-0485	1
C13	MOTOR HOUSING	078-0486	1
C14	SCREW PAN HEAD POZIDRIV M4 X 20	F-SHPZ-M4-20-ST-BO	4
C15	SCREW THREAD FORMING PAN HEAD	F-TFPX-M3-8-ST-BO	2
C16	COIL SPRING	078-0487	2
C17	CARBON BRUSH (UK/EU 230V)	078-0488	2
C18	CARBON BRUSH HOLDER	078-0490	1
C19	MOTOR HOUSING PRESS BLOCK	078-0491	1
C20	SCREW THREAD FORMING PAN HEAD SLOTTED	F-TFPHS-M4-12-ST-BO	2
C21	MOTOR HOUSING CAP	078-0492	1
C22	SCREW PAN HEAD POZIDRIV M4 X 14	F-SHPZ-M4-14-ST-BO	2
D1	SCREW PAN HEAD POZIDRIV M4 X 8	F-SHPZ-M4-8-ST-BO	6
D2	SCREW THREAD FORMING SOCKET HEAD CAP M4 X 10	F-TFSC-M4-10-ST-BO	2
D3	WASHER M4	F-W-M4-080-ST-BO	1
D4	BUCKLE PLATE	078-0493	1
D5	TRIANGLE DISC FRONT COVER ASSEMBLY	078-0494	1
D6	FRONT COVER	078-0495	1
D7	BEARING 699	F-B-699	1
D8	WASHER 9 X 20 X 0.2	F-W-9-20-020-ST-BO	1
D9	COPPER BUSHING	078-0496	1
D10	LINK GEAR SHAFT	078-0497	1
D11	CIRCLIP 10	F-CCINT-10-ST-BO	1
D12	GEAR NO.2	078-0498	1
D13	GEAR NO.1	078-0499	1
D14	BEARING 606 Z2	F-B-606-Z2	1
D15	ROUND PIN 4 X 10	078-0500	1
D16	REAR COVER	078-0501	1
D17	BEARING 6900 RS	F-B-6900-RS	1
D18	CIRCLIP 22	F-CCEXT-22-ST-BO	1
D19	SKELETON OIL SEAL $\phi 24 \times \phi 17.3 \times 3$	078-0502	1
D20	ECCENTRIC SHAFT	078-0503	1

Item	Description	Part No	Qty
D21	WOODRUFF KEY 3 X 8	078-0504	1
D22	SCREW PAN HEAD POZIDRIV M4 X 12	F-SHPZ-M4-12-ST-BO	1
D23	ANTI SPIN CAP	078-0505	1
D24	SPRING	078-0506	1
D25	SCREW PAN HEAD POZIDRIV M4 X 16	F-SHPZ-M4-16-ST-BO	23
D26	TRIANGLE PLATE DUST COLLECTION CHANNEL	078-0507	1
D27	TRIANGULAR DISK BASE	078-0508	1
D28	SCREW PAN HEAD POZIDRIV M4 X 14	F-SHPZ-M4-14-ST-BO	6
D29	ANTI ROTATION PIN	078-0509	1
D30	TRIANGLE PAD	078-0510	1
D31	RUBBER BUSH	078-0511	3
D32	SOFT STRIP	078-0527	3
D33	WASHER 14 X 4 X 1	F-W-14-4-1-ST-BO	4
D34	O-RING 9 X 4 X 2.4	078-0528	4
D35	SCREW THREAD FORMING M4 X 12	F-TFPX-M4-12-ST-BO	4
D36	ECCENTRIC BLOCK	078-0514	1
D37	CIRCLIP 15	F-CCINT-15-ST-BO	1
D38	BEARING ALUMINUM COVER ASSEMBLY	078-0515	1
D39	CIRCLIP 26	F-CCINT-23-ST-BO	1
D40	BEARING 60002 RS	F-B-60002-RS	1
D41	TRIANGULAR BEARING ALUMINUM COVER	078-0516	1
D42	TRIANGLE GRINDER	078-0517	1
D43	SCREW CROSS HEAD TAPPING M4 X 8	F-TFPX-M4-8-ST-BO	3
E1	SCREW PAN HEAD POZIDRIV M4 X 8	F-SHPZ-M4-8-ST-BO	6
E2	SCREW THREAD FORMING SOCKET HEAD CAP M4 X 10	F-TFSC-M4-10-ST-BO	2
E3	WASHER M4	F-W-M4-080-ST-BO	1
E4	BUCKLE PLATE	078-0493	1
E5	DISK FRONT COVER ASSEMBLY	078-0494	1
E6	FRONT COVER	078-0495	1
E7	BEARING 699	F-B-699	1
E8	WASHER 9 X 20 X 0.2	F-W-9-20-020-ST-BO	1
E9	COPPER BUSHING	078-0496	1
E10	LINK PINION	078-0518	1
E11	FINAL GEAR	078-0519	1
E12	BEARING 606 Z2	F-B-606-Z2	1
E13	ROUND PIN 4 X 10	078-0500	1
E14	REAR COVER	078-0501	1
E15	BEARING 6900 RS	F-B-6900-RS	1
E16	CIRCLIP 22	F-CCEXT-22-ST-BO	1
E17	SKELETON OIL SEAL	078-0502	1
E18	OUTPUT SHAFT	078-0520	1
E19	SCREW PAN HEAD POZIDRIV M2.9 X 13	F-SHPZ-M2-13-ST-BO	6
E20	WASHER 8.5 X 3.2 X 1	F-W-8.5-3.2-1-ST-BO	6
E21	RUBBER SLEEVE	078-0525	1
E22	DISK	078-0521	1
E23	SCREW PAN HEAD POZIDRIV M4 X 14	F-SHPZ-M4-14-ST-BO	6
E24	DUST RING	078-0526	1
E25	SCREW CROSS HEAD TAPPING M4 X 14	F-TFPX-4-14-ST-BO	6
E26	BUSH SEAT SPRING	078-0522	6
E27	BRUSH HOUSING	078-0523	1
E28	ROUND SANDING PAD	078-0524	1
E29	WASHER 6	F-W-6-ST-BO	1
E30	SCREW THREAD FORMING SOCKET HEAD CAP M6 X 14	F-TFSC-M6-14-ST-BO	1
F1	4.8M TELESCOPIC TUBE	078-0225	1
F2	INTERMEDIATE JOINT	078-0226	1
F3	HEXAGON SOCKET WRENCH	078-0227	1
F4	DUAL PURPOSE SCREWDRIVER	078-0228	1
F5	HOSE FITTINGS	078-0229	1
F6	HOSE FITTINGS	078-0230	1