













evolution
evolutionpowertools.com

Service Parts List	V2	S355MCS-G2	ALL PARTS
355mm Mitre Chop Saw		AUS 220-240V	102-0006A

Item DescriptionPart NoQty				Item DescriptionPart NoQty				Item DescriptionPart NoQty			
A1	ARBOUR COVER SCREW	083-0101	2	D9	POZI PAN HEAD SCREW M5X30 W/ WASHER	F-SPHPZ-M5-30-ST-BO	4	G1	HEX BOLT M5*16 WITH WASHER	F-SFCS-M5-16-ST-BO	1
A2	ARBOUR COVER	083-0102	1	D10	END CAP BLUE	084-0131	1	G2	TABLE LOCKING KNOB (BLUE)	102-0123	1
A3	LOCKING NUT M6	F-NSH-M6-ST-BO	1	D11	POZI PAN HEAD TAPPING SCREW ST4X16	F-TFPX-4-16-ST-BO	2	G3	PUSH ROD	102-0124	1
A4	SOCKET CAP SCREW M10X25	F-SHCS-M10-25-ST-BO	1	D12	POZI PAN HEAD SCREW M4X10	F-SPHPZ-M4-10-ST-BO	2	G4	LOCKING PIN	102-0125	1
A6	BLADE WASHER	083-0103	1	D13	BRUSH HOLDER	083-0152	2	G5	FRICTION WASHER	102-0126	3
A7	FLANGE B9	083-0104	2	D14	CARBON BRUSH 220V-240V	083-0153	2	G6	CROSS HEAD SCREW M5*12	F-SPHPZ-M5-12-ST-BO	5
A9	CIRCLIP Ø48	F-CCEXT-48-120-ST-BO	1	D15	BRUSH HOLDER COVER	083-0155	2	G7	RAIL LOCK SCREW	102-0127	3
A10	POZI PAN HEAD SCREW M5X14	F-SPHPZ-M5-14-ST-BO	4	D16	PCB ASSEMBLY 230V	084-0322	1	G8	LEVER SPRING	102-0128	1
A11	SPRING WASHER Ø5	F-SWA-M5-ST-BO	3	D17	MAGNETIC RING HOLDER	053-0267	1	G9	TABLE POSITIONING HANDLE (BLUE)	102-0129	1
A12	POZI PAN HEAD SCREW M6X12	F-SPHPZ-M6-12-ST-BO	1	D18	MAGNETIC RING	053-0265	1	G10	TABLE POSITIONING PLATE	102-0130	1
A13	BLADE HEAD ASSEMBLY 355	083-0105	1	D19	MAGNETIC RING COVER	053-0266	1	G11	TABLE	102-0131	1
A14	MOVING GUARD SPRING SPACER 355	083-0106	1	D20	POZI PAN HEAD SCREW M4-14	F-SPHPZ-M4-14-ST-BO	1	G12	CROSS HEAD SCREW M5*8	F-SCHS-M5-8-ST-BO	10
A15	MOVING GUARD SPRING	083-0107	1	D21	TERMINAL BLOCK 6 HOLES	053-0288	1	G13	CROSS HEAD SCREW M5*10 WITH WASHER	F-SPHPZ-M5-10-ST-BO	1
A16	SOCKET CAP SCREW M5X12	F-SHCS-M5-12-ST-BO	1	D202	ARMATURE 65 ASSEMBLY 110-120V UK/USA	084-0050	1	G14	MITRE INDICATOR (BLUE)	102-0132	1
A17	BALL BEARING 606	F-B-606-2Z	1					G15	HEX BOLT M6*45	F-SCHS-M6-45-ST-BO	4
A18	BUMP STOP	083-0108	1	E1	ARM	083-0160	1	G16	NUT M6	F-NNIF-M6-ST-BO	4
A19	BUMP STOP FIXING	083-0109	1	E2	ARBOUR LOCKING PIN	083-0161	1	G17	LEFT RAIL	102-0133	1
A20	SLIDER CAP	083-0110	1	E3	ROLLER PIN 4X20	F-SDL-4-20-ST-BO	1	G18	RIGHT RAIL	102-0134	1
A21	MOVING GUARD ASSEMBLY 355	083-0111	1	E4	LOCKING PIN SPRING	083-0162	1	G19	BEVEL BRACKET COVER	102-0135	2
A100	LED HOUSING ASSEMBLY 355	083-0311	1	E5	BALL BEARING 6000 YQ	F-B-6000-2Z	2	G20	RAIL BEARING Ø40*Ø25*30	102-0136	4
A22	LED HOUSING LH 355	083-0300	1	E6	CIRCLIP Ø16	F-CCEXT-16-100-ST-BO	1	G21	LOCK DOWN PIN	102-0137	1
A23	LED HOUSING RH 355	083-0301	1	E7	1ST DRIVE GEAR	083-0163	1	G22	DEEP POSITION CAP	102-0138	1
A24	M5 SCREW COUNTERSUNK M5X8	F-SCHPZ-M5-8-ST-BO	1	E8	KEY 5X5X12	083-0164	1	G23	HEX BOLT SCREW M8*30	F-SHCS-M8-30-ST-BO	1
A25	M4 SCREW PAN HEAD M4X14	F-TFPX-M4-14-ST-BO	1	E9	GEAR SHAFT	083-0165	1	G24	PIVOT SHAFT	102-0139	1
A26	LED SPACER	084-0309	1	E10	BALL BEARING 6200 YQ	F-B-6200-2Z	1	G25	PIN	102-0140	1
A27	LED RETAINER	084-0310	1	E11	CIRCLIP Ø17	F-CCEXT-17-100-ST-BO	1	G26	O RING 10*1.9	102-0141	1
A28	LED PCBA	084-0311	1	E12	2ND DRIVE GEAR	083-0166	1	G27	E CLIP 8MM	F-ECLIP-8-100-ST-BO	1
A29	LED GLASS SHEILD	084-0312	1	E13	GEAR SPACER	083-0167	1	G28	NECK- BEVEL BRACKET	102-0142	1
A30	CORRUGATED PIPE 280MM	084-0308	1	E14	SOCKET CAP SCREW M5X12	F-SHCS-M5-12-ST-BO	2	G29	SET SSCFP-M6*18	F-SSCFP-M6-8-ST-BO	2
A31	LED HOUSING PRODUCT PLAQUE S355MCS	102-0164	1	E15	SPRING WASHER Ø5	F-SWA-M5-ST-BO	2	G30	RAIL LOCK PIN	102-0143	1
A33	M3 DOUBLE SIDED ADHESIVE TAPE 0.21MM	083-0313	1	E16	BEARING BRACKET	083-0168	1	G31	RAIL LOCK HANDLE	102-0144	1
				E17	BALL BEARING 6203 YQ	F-B-6203-2Z	1	G32	HEAD SPRING	102-0145	1
B1	LINKAGE SHOULDER SCREW UPPER	083-0115	1	E18	KEY 6X6X14	083-0169	1	G33	PIN STOP- FOR PACKAGING	102-0146	1
B2	SCREW SPACER	083-0116	1	E19	GEAR BOX COVER	083-0170	1	G34	RAIL POSITIONING PIN	102-0147	1
B3	SMALL LINKAGE	083-0117	1	E20	ARBOUR SHAFT	083-0171	1	G35	RAIL PIN SPRING	102-0148	1
B4	LINKAGE SHOULDER SCREW MIDDLE	083-0118	1	E21	PLUM BLOSSOM CAP COUNTERSUNK SCREW M5X15	F-SCHPZ-M5-15-ST-BO	4	G36	RAIL POSITIONING PLATE	102-0149	1
B5	MAIN LINKAGE	083-0119	1	E22	RUBBER BEARING RING	083-0196	1	G37	SQUARE NUT M10	F-NS-M10-ST-BO	1
B6	LINKAGE SHOULDER SCREW LOWER	083-0120	1	E23	CHIP GUARD	084-0170	1	G38	RAIL PIN CAP	102-0150	1
B7	WAVE WASHER M10	FWW-M10-ST-BO	1	E24	CROSS HEAD SCREW M5X10	F-SPHPZ-M5-10-ST-BO	2	G39	RAIL SUPPORT BRACKET	102-0150	1
B8	NUT M6	F-NNIF-M6-ST-BO	1	E201	GEARBOX ASSEMBLY (S355)	084-0055	1	G40	HEX BOLT SCREW M6*20 WITH WASHER	F-SFCS-M6-20-ST-BO	2
								G41	HEX BOLT SCREW M10*50 WITH WASHER	F-SFCS-M10-50-ST-BO	4
C1	MAIN HANDLE LOWER	083-0306	1	F1	HEX BOLT M5*16 WITH WASHER	F-SFCS-M5-16-ST-BO	2	G42	HEXKEY M6 & M10	F-HEXKEY-M6/10-ST-BO	1
C2	TERMINAL BLOCK	083-0122	2	F2	BANNER LOCK KNOB	102-0101	2	G43	GROMMET	102-0152	1
C3	CAPACITOR 220-240V	083-0123	1	F3	BANNER ROD	102-0102	2	G44	FENCE MCS LH	102-0169	1
C4	TRIGGER	084-0304	1	F4	SLIDING BASE	102-0103	2	G45	FENCE MCS RH	102-0170	1
C5	MAIN TRIGGER SPRING	083-0126	1	F5	CLAMP PIN	102-0104	2	G46	BASE	102-0155	1
C6	TRIGGER SWITCH	084-0307	1	F6	BANNER MOVE NUT	102-0105	2	G47	BEARING SCREW M8*12	102-0156	2
C7	TRIGGER LOCK SPRING	083-0128	1	F7	WASHER 20*10*2	F-W-M10-ST-BO	3	G48	WING SPRING	102-0157	2
C8	LOCK TRIGGER	083-0129	1	F8	WORKPIECE CLAMP	102-0106	3	G49	WING SCREW	102-0158	2
C9	TRIGGER LOCK PIN	083-0130	1	F10	CROSS HEAD SCREW M5*12 WITH WASHER	F-SPHPZ-M5-12-ST-BO	3	G50	MITRE PLATE	102-0159	1
C10	MAIN HANDLE UPPER	083-0307	1	F11	SPRING BEARING INSERT	102-0107	6	G51	RUBBER FOOT	102-0160	4
C11	POZI PAN HEAD SCREW M5X30 W/ WASHER	F-SPHPZ-M5-30-ST-BO	4	F12	V CLAMP STAMPING	102-0109	3	G52	CROSS HEAD SCREW M6*12	F-SPHPZ-M6-12-ST-BO	3
C12	POZI PAN HEAD SCREW M5X30 W/ WASHER	F-SPHPZ-M5-30-ST-BO	2	F13	WORK PIECE CLAMP (BLUE)	102-0110	1	G53	LOCK NUT M10	F-NNIF-M10-ST-BO	1
C13	CARRY HANDLE	083-0132	1	F14	VERTICAL CLAMP PIN	102-0111	1	G54	WASHER 10MM	F-W-M10-ST-BO	1
C14	CABLE SLEEVE SMALL	083-0133	1	F15	VERTICAL CLAMP NUT	102-0112	1	G55	HEX BOLT SCREW M10*35	F-SHCS-M10-35-ST-BO	1
C15	CABLE AUS 220-240V/3M	084-0114	1	F16	CIRCLIP EXTERNAL 16MM	F-CCEXT-16-100-ST-BO	1	G56	KERF PLATE	102-0162	1
C16	CABLE STRAIN CLAMP	083-0140	1	F17	VERTICAL CLAMP KNOB	102-0113	1	G57	MAIN TORSION SPRING SPACER	083-0190	1
C18	INDUCTOR	083-0195	1	F18	VERTICAL CLAMP KNOB SPRING	102-0114	1	G58	FELT WASHER	102-0163	2
C21	LED SWITCH	084-0314	1	F19	CLAMP ARM	102-0115	1				
C22	LED PSU PCBA 230V AC	084-0315	1	F20	VERTICAL CLAMP BUTTON	102-0116	1				
C23	POZI PAN HEAD TAPPING SCREW ST4X16	F-TFPX-4-16-ST-BO	11	F21	VERTICAL CLAMP SPRING	102-0117	1				
C24	SWITCH BUTTON	084-0305	1	F22	VERTICAL CLAMP SPRING CAP	102-0118	1				
				F23	CROSS HEAD SCREW M4*10 WITH WASHER	F-SPHPZ-M4-10-ST-BO	1				
D1	BALL BEARING 6202 YQ	F-B-6202-2Z	1	F24	VELTIC POLE	102-0119	1				
D2	ARMATURE 65/220V-240V 2200W	084-0121	1	F25	HEX BOLT SCREW M6*30	F-SCHS-M6-30-ST-BO	4				
D3	BALL BEARING 629 YQ	F-B-629-2Z	1	F26	FRONT CLAMP BAR	102-0120	1				
D4	POZI PAN HEAD TAPPING SCREW ST5X80	F-TFPX-5-80-ST-BO	2	F27	SET SCREW M6*8	F-SSCFP-M6-8-ST-BO	2				
D5	AIR BAFFLE 65	084-0125	1	F28	FRONT CLAMP ARM	102-0121	2				
D6	STATOR 65/220V-240V 2200W	084-0127	1	F29	FRONT CLAMP POST	102-0122	2				
D7	BALL BEARING CAP	053-0270	1								
D8	MOTOR HOUSING	083-0150	1								

evolution®

evolutionpowertools.com

Service Parts List

V2

S355MCS-G2

AUS 220-240V

ALL PARTS

102-0006A