




evolutionpowertools.com

ALL PARTS

116-0001
116-0003

Service Parts List	V1.0	R210MTS G2
210mm Table Mitre Saw G2		230V

No.	Description	Part Code	Qty	No.	Description	Part Code	Qty	No.	Description	Part Code	Qty
A1	BASE	116-0101	1	B34	LOWER GUARD RIGHT	116-0140	1	E3	PAN SCREW M4 X 16	F-TFPX-M4-16-ST-BO	5
A2	REAR SUPPORT STAND	116-0102	1	B35	FLANGE INNER	116-0141	1	E4	CAP SCREW M5 X 14	F-SHCS-M5-14-ST-BO	4
A3	FENCE FIXED	116-0103	1	B36	ARBOR BOLT	116-0142	1	E5	SPRING WASHER M5	F-SWA-M5-ST-BO	4
A4	FLANGED CAP SCREW M6 X 20	F-SFCS-M6-20-ST-BO	10	B37	LOWER GUARD LEFT	116-0143	1	E6	FLAT WASHER M5	F-W-M5-ST-BO	4
A5	FOOT	116-0104	5	B38	MITRE SAW DUST PORT RIGHT	116-0144	1	E7	TABLE PIVOT ARM CAP	116-0193	1
A6	BASE EXTENSION	116-0105	2	B39	MITRE SAW DUST PORT LEFT	116-0145	1	E8	TABLE PIVOT ARM SCREW M6	116-0194	1
A7	TOP CLAMP KNOB SCREW M6	116-0106	1	B40	LOWER GUARD PIVOT SHAFT	116-0146	1	E9	NYLOC NUT M6	F-NNIF-M6-ST-BO	1
A8	PAN SCREW M5 X 8	F-SPHPZ-M5-8-ST-BO	4	B41	MITRE SAW DUST PORT RING CAP	116-0147	1	E10	TABLE PIVOT BRACKET	116-0195	1
A9	MITRE LOCK KNOB	116-0107	1	B42	LEFT HEAD FRAME COVER	116-0148	1	E11	TABLE TOP	116-0196	1
A10	MITRE LOCK PIN	116-0108	1	B43	PAN SCREW M5 X 40	F-SFPX-M5-40-ST-BO	2	E12	TABLE TOP BLANKING PLATE	116-0197	1
A11	MITRE LOCK ARM BRACKET	116-0109	1					E13	RIVING KNIFE	116-0198	1
A12	MITRE RELEASE BUTTON	116-0110	1	C1	UPPER FRONT HANDLE	116-0149	1	E14	RIVING KNIFE GUIDE BRACKET	116-0199	1
A13	MITRE POINTER	116-0111	1	C2	FLANGED PAN SCREW M5 X 30	F-SPHPZ-M5-30-ST-BO	4	E15	TABLE KERF PLATE	116-0200	1
A14	FLANGED PAN SCREW M5 X 10	F-SFPX-M5-10-ST-BO	1	C3	HANDLE WIRE CAP	116-0150	2	E16	CAP SCREW M6 X 20	F-SHCS-M6-20-ST-BO	2
A15	MITRE TABLE	116-0112	1	C4	TERMINAL CONNECTOR	116-0151	1	E26	TABLE SCALE MARKINGS METRIC (UK / EU / AUS)	116-0205	1
A16	MITRE KERF PLATE	116-0113	1	C5	PAN SCREW M4 X 8	F-TFPHS-M4-8ST-BO	2	E100	BLADE GUARD ASSEMBLY	116-0216	1
A17	CAP SCREW M6 X 16	F-SHCS-M6-16-ST-BO	3	C6	TABLE TOP PIVOT SAFETY SWITCH BUTTON BRACKET	116-0152	1				
A18	NUT M6	F-NSF-M6-ST-BO	3	C7	TABLE TOP PIVOT SAFETY SWITCH BUTTON	116-0153	1	F100	FENCE ASSEMBLY	116-0217	1
A19	MITRE LOCK PUSH ROD	116-0114	1	C8	TABLE TOP PIVOT SAFETY SWITCH BUTTON SPRING	116-0154	1				
A20	BEVEL POINTER	116-0115	1	C9	TABLE TOP PIVOT SAFETY SWITCH BUTTON SPRING CAP	116-0155	1	G100	TOP CLAMP	116-0218	1
A21	CAP SCREW M5 X 12	F-SHCS-M5-12-ST-BO	2	C10	TABLE TOP PIVOT SAFETY SWITCH	116-0156	1				
A22	BEVEL BLOCK	116-0116	1	C11	MITRE SAW ON / OFF SWITCH	116-0157	1				
A23	BEVEL LOCK LEVER	116-0117	1	C12	TABLE SAW ON / OFF SWITCH	116-0158	1				
A24	FLAT WASHER M8	F-W-M8-ST-BO	1	C13	LOWER FRONT HANDLE	116-0159	1				
A25	NYLOC NUT M10	F-NNIF-M10-ST-BO	1	C14	SCREW M4 X 16	F-TFPHS-M4-16ST-BO	4				
A26	SPRING WASHER M10	F-SWA-M10-ST-BO	1								
A27	FLAT WASHER M10	F-W-M10-ST-BO	1	D1	FLANGED PAN SCREW M5 X 30	F-SPHPZ-M5-30-ST-BO	4				
A28	BEVEL BLOCK FLIP STOP	116-0118	1	D2	PAN SCREW M4 X 16	F-TFPX-M4-16-ST-BO	2				
A29	COUNTER SINK SCREW M6 X 30	F-SCHPZ-M6-30-ST-BO	2	D3	MOTOR ENDCAP	116-0160	1				
				D4	CARBON BRUSH ASSEMBLY	116-0161	2				
B1	HEAD ROTATION LEVER ARM	116-0119	1	D5	MOTOR HOUSING CABLE GROMMET	116-0162	1				
B2	HEAD ROTATION LEVER KNOB	116-0120	1	D6	MOTOR HOUSING	116-0163	1				
B3	COUNTER SINK SCREW M5 X 12	F-SCHPZ-M5-12-ST-BO	3	D7	MOTOR REAR BEARING CAP	116-0164	1				
B4	LOWER BLADE GUARD LEVER BRACKET	116-0121	1	D8	ARMATURE 230V (UK / EU / AUS)	116-0165	1				
B5	LOWER BLADE GUARD SPRING	116-0122	1	D9	FIELD COIL 230V (UK / EU / AUS)	116-0167	1				
B6	LOWER BLADE GUARD LEVER	116-0123	1	D10	PAN SCREW M4 X 65	F-TFPX-M4-65-ST-BO	2				
B7	TABLE SAW DUST SHOOT	116-0124	1	D11	TABLE PIVOT RELEASE KNOB	116-0169	1				
B8	SCREW	116-0214	1	D12	MOTOR AIR BAFFLE	116-0170	1				
B9	HEAD FRAME	116-0125	1	D13	TABLE PIVOT BRACKET SCREW M8 X 12	116-0171	1				
B10	HEAD PIVOT SAFETY CATCH SPRING	116-0126	1	D14	WAVE WASHER M10	F-WW-M10-ST-BO	1				
B11	HEAD PIVOT SAFETY CATCH ROD	116-0127	1	D15	TABLE PIVOT ARM	116-0172	1				
B12	ECLIP INTERNAL 6MM	F-ECLIP-6-ST-BO	1	D16	GEARBOX HOUSING	116-0173	1				
B13	HEAD PIVOT SAFETY CATCH GUIDE BRACKET	116-0128	1	D17	TABLE PIVOT RELEASE KNOB SPRING SHROUD	116-0174	1				
B14	FLANGED PAN SCREW M4 X 10	F-SFPX-M4-10-ST-BO	2	D18	TABLE PIVOT RELEASE KNOB SPRING	116-0175	1				
B15	MOTOR PIVOT SPRING	116-0129	1	D19	TABLE PIVOT RELEASE KNOB SHAFT	116-0176	1				
B16	PAN SCREW M5 X 20	F-SPHPZ-M5-20-ST-BO	2	D20	NYLOC NUT M10	F-NNIF-M10-ST-BO	1				
B17	SWITCH WIRING COVER BRACKET	116-0130	1	D21	FLAT WASHER M10	F-W-M10-ST-BO	1				
B18	PAN SCREW M5 X 14	F-SPHPZ-M5-14-ST-BO	1	D22	CIRCLIP INTERNAL 33MM	F-CCINT-33-ST-BO	1				
B19	HEAD PIVOT SHAFT	116-0131	1	D23	COUNTERSINK SCREW M5 x 16	F-SCHPZ-M5-16-ST-BO	1				
B20	TORSION SPRING HEAD	116-0132	1	D24	MOTOR WOODRUFF KEY	116-0177	1				
B21	TORSION SPRING HEAD SHROUD	116-0133	1	D31	PAN SCREW M5 X 40	F-SPHPZ-M5-40-ST-BO	2				
B22	FLANGED PAN SCREW M5 X 30	F-SFPX-M5-30-ST-BO	1	D32	ELECTRONICS HOUSING RIGHT	116-0181	1				
B23	HEAD PIVOT RELEASE KNOB	116-0134	1	D33	POWER CABLE & PLUG 230V (UK)	116-0182	1				
B24	CAP SCREW M6 X 16	F-SHCS-M6-16-ST-BO	1	D34	PAN SCREW M4 X 16	F-TFPX-M4-16-ST-BO	4				
B25	HEAD PIVOT STOP	116-0135	1	D35	CABLE STRAIN RELIEF CLAMP	116-0186	1				
B26	F-SDH-600-30-ST-BO	F-SDH-600-30-ST-BO	1	D36	CABLE STRAIN RELIEF	116-0187	1				
B27	PAN SCREW M4 X 14	F-TFPHS-M4-14-ST-BO	4	D37	TERMINAL CONNECTOR	116-0188	2				
B28	PAN SCREW M4 X 10	F-SPHS-M4-10-ST-BO	1	D38	PCB	116-0189	1				
B29	FLAT WASHER M4	F-W-M4-ST-BO	1	D39	ELECTRONICS HOUSING LEFT	116-0190	1				
B30	SPRUNG LOWER GUARD BLADE COVER	116-0136	1	D100	ARBOR SHAFT ASSEMBLY	116-0215	1				
B31	SPRUNG LOWER GUARD BLADE COVER SPRING	116-0137	1								
B32	TORSION SPRING LOWER GUARD	116-0138	1	E1	UPPER BLADE GUARD LEFT	116-0191	1				
B33	HEAD ROTATION LEVER ARM SHAFT	116-0139	1	E2	UPPER BLADE GUARD RIGHT	116-0192	1				



ALL PARTS
116-0001
116-0003

Service Parts List

V1.0

R210MTS G2

210mm Table Mitre Saw G 2

230V