




evolution
POWER TOOLS

RAGE3-DB

Dual Rail Slide Mitre Saw
043-0001.01

Service Parts List

Item	Description	Part No	Qty	Item	Description	Part No	Qty	Item	Description	Part No	Qty
M1	Back clamp unit	EV3DBSM1	1	73	Torsion spring	EV3DBS73	1	173	Hex screw M4x12	EV3DBS173	1
M2	Bevel lever kit	EV3DBSM2	1	76	Extension support	EV3DBS76	2	174	Retaining washer	EV3DBS174	1
M3	Extension support stop	EV3DBSM3	1	82	Cap screw	EV3DBS82	1	175	Middle lid	EV3DBS175	1
M4	Laser unit kit	EV3DBSM4	1	83	Cable clamp	EV3DBS83	1	176	Belt adjusting block	EV3DBS176	1
M5	Guard mech kit	EV3DBSM5	1	84	Cross head screw M4x10	EV3DBS84	2	177	Hex set screw M8x20	EV3DBS177	1
M7	Gearbox unit	EV3DBSM7	1	85	Limiting stop screw	EV3DBS85	1	178	Spring washer 5mm	EV3DBS178	2
M8	Channel guide kit	EV3DBSM8	1	86	Lockdown pin knob	EV3DBS86	1	179	Hex screw M5x25	EV3DBS179	2
1	Nylock nut M12	EV3DBS1	1	87	"O" seal ring	EV3DBS87	1	180	Cross head screw M4x10	EV3DBS180	2
2	Flat washer 12mm	EV3DBS2	2	88	Main sliding shaft seal ring	EV3DBS88	2	181	Exhaust port tube	EV3DBS181	1
3	Wave washer 12mm	EV3DBS3	1	89	Linear ball bearing	EV3DBS89	2	182	Countersunk screw	EV3DBS182	1
4	Cross head screw M4x14	EV3DBS4	4	90	Bearing separator sleeve	EV3DBS90	1	183	Flat washer 6mm	EV3DBS183	4
5	Washer 5mm	EV3DBS5	4	91	Rocker pin left	EV3DBS91	1	184	Spring washer 6mm	EV3DBS184	4
6	Rubber foot	EV3DBS6	4	92	Lockdown pin knob	EV3DBS92	1	185	Hex screw M6x16	EV3DBS185	4
7	Base	EV3DBS7	1	93	Angle limit bearing pin	EV3DBS93	1	186	Transformer box	EV3DBS186	1
8	Table positioning handle	EV3DBS8	1	94	Pin 4x20	EV3DBS94	1	187	Gearbox housing	EV3DBS187	1
9	Positioning handle stop	EV3DBS9	1	95	Pin 4x30	EV3DBS95	2	188	Head stop block	EV3DBS188	1
10	Spring	EV3DBS10	1	96	Pin	EV3DBS96	1	189	Cross head screw M4x10	EV3DBS189	1
11	Swinging handle	EV3DBS11	1	97	Spring washer 4mm	EV3DBS97	2	190	Wing nut M6	EV3DBS190	1
12	Screw M5x10	EV3DBS12	2	98	Flat washer 4mm	EV3DBS98	2	191	Limiting handwheel	EV3DBS191	1
13	Handle support	EV3DBS13	1	99	Hex set screw M6x20	EV3DBS99	2	192	Gear locking knob	EV3DBS192	1
14	Positioning handle screw	EV3DBS14	1	100	Hex nut M6	EV3DBS100	2	193	Cross head screw M4x10	EV3DBS193	1
18	Table angle indicator	EV3DBS18	1	101	Hex set screw M6x12	EV3DBS101	2	194	Cable clamp	EV3DBS194	2
20	Cross head screw M5x10	EV3DBS20	1	102	Cross head screw M5x10	EV3DBS102	2	195	Terminal block	EV3DBS195	3
21	Table	EV3DBS21	1	103	Rocker pin right	EV3DBS103	1	196	Self-tapping screw ST4x12	EV3DBS196	4
22	Table screw	EV3DBS22	1	104	Flat washer 16mm	EV3DBS104	2	197	Laser Transformer 110v	EV3DBS197	1
26	Clamp knob	EV3DBS26	4	105	Wave washer 16mm	EV3DBS105	1	197A	Laser Transformer 230v	EV3DBS197A	1
28	Nylock nut M6	EV3DBS28	1	107	Self-locking nut M16	EV3DBS107	1	198	Transformer box lid	EV3DBS198	1
29	Table locking lever	EV3DBS29	1	111	Flat washer 5mm	EV3DBS111	2	199	Laser switch	EV3DBS199	1
30	Cross head screw M5x10	EV3DBS30	3	112	Spring washer 5mm	EV3DBS112	2	200	Belt housing	EV3DBS200	1
31	Locking lever clamp	EV3DBS31	1	113	Hex bolt M5x16	EV3DBS113	2	201	Cross head screw M4x14	EV3DBS201	2
32	Locking lever shim	EV3DBS32	1	114	Rocker cover board	EV3DBS114	2	202	Dust bag	EV3DBS202	1
33	Anti friction ring	EV3DBS33	2	115	Wire clamp	EV3DBS115	1	203	Brush holder cap	EV3DBS203	2
34	Cross head screw M4x10	EV3DBS34	4	116	Cable sheath	EV3DBS116	1	204	Carbon brush (pr)	EV3DBS204	2
35	Fence right extension	EV3DBS35	1	117	Cross head screw	EV3DBS117	2	205	Back cover	EV3DBS205	1
36	Left handle	EV3DBS36	1	118	Cable & plug 110v UK	EV3DBS118	1	206	Tapping screw ST4x12	EV3DBS206	2
37	Spring for lock switch	EV3DBS37	1	118A	Cable & plug 230v UK	EV3DBS118A	1	207	Tapping screw	EV3DBS207	2
38	Lock switch knob	EV3DBS38	1	119	Support	EV3DBS119	1	208	Motor housing	EV3DBS208	1
39	Middle connect rod lock switch	EV3DBS39	1	120	Hex screw M8x25	EV3DBS120	3	209	Brush holder	EV3DBS209	2
40	Lower connect rod lock switch	EV3DBS40	1	121	Scale label	EV3DBS121	1	210	Cross head screw M5x35	EV3DBS210	4
41	Hex screw M8x18 (Left hand)	EV3DBS41	1	122	Support bearing pin	EV3DBS122	1	211	Spring washer 5mm	EV3DBS211	4
42	Washer 8mm	EV3DBS42	1	123	Cross head screw M3x8	EV3DBS123	1	212	Washer 5mm	EV3DBS212	4
43	Fence left extension	EV3DBS43	1	129	Gear lock spring	EV3DBS129	1	213	Flat washer 5mm	EV3DBS213	2
44	Outer flange	EV3DBS44	1	130	Gear lock clamp	EV3DBS130	1	214	Spring washer 5mm	EV3DBS214	2
46	Inner flange	EV3DBS46	1	131	Frame cover plate	EV3DBS131	1	215	Tapping screw ST5x75	EV3DBS215	2
47	Circlip 40mm	EV3DBS47	1	132	Cross head screw M4x10	EV3DBS132	2	216	Ball bearing 629	EV3DBS216	1
48	Moving blade guard	EV3DBS48	1	133	Terminal box	EV3DBS133	1	217	Ball bearing 6201	EV3DBS217	1
49	Cross head screw M4x16	EV3DBS49	4	134	Cross head screw	EV3DBS134	2	218	Pulley 2	EV3DBS218	1
50	Spring washer 4mm	EV3DBS50	4	136	Terminal block	EV3DBS136	1	219	Washer 5mm	EV3DBS219	2
51	Flat washer 4mm	EV3DBS51	4	137	Cross head screw M4x32	EV3DBS137	4	220	Spring washer 5mm	EV3DBS220	2
52	Guard return spring	EV3DBS52	1	138	Terminal box lid	EV3DBS138	1	221	Hex screw M5x16	EV3DBS221	2
53	Hex bolt M8x35	EV3DBS53	4	139	Belt	EV3DBS139	1	222	Flat key 5x5x16	EV3DBS222	1
54	Flat washer 8mm	EV3DBS54	4	140	Handle	EV3DBS140	1	223	Armature 110v	EV3DBS223	1
55	Set rule	EV3DBS55	1	141	Hex screw M8x16	EV3DBS141	1	223A	Armature 230v	EV3DBS223A	1
56	Hex set screw M6x12	EV3DBS56	2	142	Grub screw M8x16	EV3DBS142	4	224	Field coil 110v	EV3DBS224	1
57	Capacitor	EV3DBS57	1	143	Hex nut M8	EV3DBS143	4	224A	Field coil 230v	EV3DBS224A	1
58	Inductor	EV3DBS58	1	144	Spring	EV3DBS144	1	225	Label set 110v	EV3DBS225	1
59	Double aperture terminal	EV3DBS59	1	145	Set handwheel	EV3DBS145	1	225A	Label set 230v	EV3DBS225A	1
60	Right handle	EV3DBS60	1	146	Sliding bar supporting pad	EV3DBS146	4	226	Magnet	EV3DBS226	1
61	On/Off Switch	EV3DBS61	1	147	Rocker setting block	EV3DBS147	1	227	Speed sensor	EV3DBS227	1
62	Self-tapping screw ST4x20	EV3DBS62	9	148	Main sliding shaft seal ring	EV3DBS148	2	228	PCB 110v	EV3DBS228	1
63	Middle connect rod spring	EV3DBS63	1	149	Back support	EV3DBS149	1	228A	PCB 230v	EV3DBS228A	1
64	Secondary sliding bar	EV3DBS64	1	150	Cable sheath	EV3DBS150	1				
65	Cross head screw M4x10	EV3DBS65	1	151	Cross head screw M4x10	EV3DBS151	2				
66	Rubber stop	EV3DBS66	2	157	Angle limit bearing pin spring	EV3DBS157	1				
67	Main sliding bar	EV3DBS67	1	161	Air baffle	EV3DBS161	1				
68	Head pivot block	EV3DBS68	1	164	Pulley 1	EV3DBS164	1				
69	Head lockdown pin	EV3DBS69	1	166	Flat key 4x4x16	EV3DBS166	1				
70	Cross head screw M5x18	EV3DBS70	2	167	Gear shaft	EV3DBS167	1				
71	Long shaft	EV3DBS71	1	168	Ball bearing 699	EV3DBS168	1				
72	Pin 6x45	EV3DBS72	4	171	Ball bearing 6001	EV3DBS171	1				

evolution
POWER TOOLS

RAGE3-DB

Dual Rail Slide Mitre Saw
043-0001.01

Service Parts List