




evolution®

R210CMS
Multipurpose Compound Mitre Saw

Service Parts List

046-0002A.02

DWG No	Part Code	Description	Qty	DWG No	Part Code	Description	Qty	DWG No	Part Code	Description	Qty
1	F-SPHPZ-M5-12-ST-BO	SCREW PAN HEAD M5X12	4	72	F-CCEXT-6-070-ST-BO	CIRCLIP EXTERNAL 6X0.7	1				
2	046-0102	HANDLE-TOP	1	73	046-0173	BASE	1				
3	046-0103	TRIGGER (RCMS)	1	74	046-0174	8MM BALL BEARING	1				
4	046-0206	CAPACITOR 110V	1	75	046-0175	COMPRESSION SPRING	1				
5	F-TFPX-8-12-ST-BO	THREAD FORMING SCREW ST4X12	6	76	046-0176	M10 X 10 SOCKET HEAD GRUB SCREW	1				
6	046-0106	CABLE CLAMP	1	77	F-NNIF-M6-ST-BO	NYLOC NUT M6	1				
7	046-0209	SWITCH 110V	1	78	046-0179	PIVOT SPRING	1				
8	046-0212	POWER CORD 110V (UK)	1	79	F-CCEXT-16-100-ST-BO	CIRCLIP EXTERNAL 16X1	2				
9	046-0109	CABLE STRAIN RELIEF	1	80	046-0181	PIVOT	1				
10	046-0110	HANDLE-BOTTOM	1	81	F-SHCS-M6-20-ST-BO	SOCKET HEAD SCREW M6X20	1				
11	F-SPHPZ-M5-25-ST-BO	SCREW PAN HEAD M5X25	4	82	F-NSH-M6-ST-BO	NUT STANDARD HALF M6	3				
12	046-0112	BRUSH HOLDER CAP	2	83	F-SSCFP-M6-14-ST-BO	SOCKET SET SCREW M6X14	2				
13	046-0232	CARBON BRUSH (Pr)	2	84	046-0186	BEVEL INDICATOR (RCMS)	1				
14	046-0114	BRUSH HOLDER	2	85	F-W-M3-ST-BO	WASHER M3	1				
15	046-0115	MOTOR HOUSING	1	86	F-SPHPZ-M3-8-ST-BO	SCREW PAN HEAD M3X8	1				
16	046-0216	ARMATURE 110V	1	87	046-0189	HEAD LOCK DOWN PIN (RCMS)	1				
17	046-0219	FIELD COIL 110V	1	88	046-0190	RUBBER O RING 10X1.9	1				
18	F-TFPX-8-50-ST-BZP	THREAD FORMING SCREW ST4X50	2	89	F-ECLIP-8-080-ST-PO	E CLIP EXTERNAL 8X0.8	1				
19	046-0119	FAN SHROUD	1	90	046-0192	PIVOT BLOCK	1				
20	046-0120	GUARD RELEASE LEVER - SHOULDER SCREW	1	91	F-SHCS-M6-18-ST-BO	SOCKET HEAD SCREW M6X18	1				
21	046-0121	GUARD RELEASE LEVER - TORSION SPRING	1	92	046-0194	BEVEL SHAFT	1				
22	046-0122	GUARD RELEASE LEVER (RCMS)	1	93	F-W-M8-ST-BO	WASHER M8	2				
23	046-0123	HEAD/BLADE HOUSING	1	94	F-NNIF-M8-ST-BO	NYLOC NUT FULL M8	1				
24	046-0124	BLADE GUARD BUMP STOP	1	95	046-0197	BEVEL LOCK LEVER (RCMS)	1				
25	F-SPHPZ-M5-16-ST-BO	SCREW PAN HEAD M5X16	1	99	F-HEXKEY-M6-ST-BO	HEX KEY M6	1				
26	046-0126	LOCK PIN - COMPRESSION SPRING	1	100	046-0202	HOLD DOWN CLAMP (RCMS)	1				
27	046-0127	LOCK PIN	1	101	046-0203	BLADE GUARD & LINKAGE	1				
28	F-SDL-400-28-ST-BO	SPRING DOWEL 4X28	1	102	046-0204	GEARBOX ASSEMBLY	1				
29	046-0129	BLADE GUARD PRESSED PLATE	1								
30	F-SPHPZ-M4-8-ST-BO	SCREW PAN HEAD M4X8	2								
40	046-0140	SCREW PAN HEAD M4X12	4								
41	046-0141	BLADE GUARD - TORSION SPRING	1								
52	046-0152	EVENTS SHEILD COIL SPRING	1								
53	046-0153	INNER FLANGE	1								
55	046-0155	OUTER FLANGE	1								
57	046-0157	M8X18 BLADE BOLT L/H THREAD	1								
58	046-0158	SLIDING FENCE	1								
59	F-SHCS-M6-25-ST-BO	SOCKET HEAD SCREW M6X25	2								
60	F-W-M6-ST-BO	WASHER M6	3								
61	046-0161	FENCE THUMB SCREW (RCMS)	1								
62	046-0162	THUMB SCREW (RCMS)	1								
63	F-SSCFP-M4-06-ST-BO	SOCKET SET SCREW M4X6	1								
64	046-0164	TABLE LOCKING SCREW (RCMS)	1								
65	046-0165	FENCE-MAIN	1								
66	046-0166	MITRE LOCK PAD	1								
67	F-HB-M6-20-ST-BO	HEXAGON BOLT M6X20	1								
68	F-SHCS-M6-12-ST-BO	SOCKET HEAD SCREW M6X12	1								
69	046-0169	CHANNEL GUIDE (RCMS)	1								
70	046-0170	TABLE	1								
71	046-0171	REAR SUPPORT BAR	1								

evolution®

R210CMS
Multipurpose Compound Mitre Saw

Service Parts List

046-0002A.02