



Item	Part No	Description	Qty	Item	Part No	Description	Qty
1	F-SPHPZ-M4-10-ST-BO	Screw M4x10	1	59	075-0241	Fan guide	1
2	075-0201	Battery box cover	1	60	F-TFPX-6-70-ST-BZP	Screw ST3.5x70	2
3	075-0202	Laser Ass	1	61A	075-0243	Field Coil 230V	1
4	F-SPHPZ-M3-8-ST-BZP	Screw M3x8	2	62	075-0244	Connecting Wire	2
5	F-TFPX-4-8-ST-BZP	Screw ST2.9x8	1	63	075-0245	Motor Housing	1
6	F-SPHPZ-M4-10-ST-BZP	Screw M4x10	1	64	075-0246	Housing insert	1
7	075-0203	Battery box Ass	1	65	075-0247	Air flow deflector	1
8	075-0204	Battery	2	66	F-NSF-M6-ST-BZP	Nut M6	1
9	075-0205	Wire Guard	1	67	075-0248	Cable Clamp	1
10	F-SPHPZ-M4-16-ST-BO	Screw M4x16	4	68	F-TFPX-8-16-ST-BZP	Screw ST 4.2x16	2
11	F-SWA-M4-ST-BZP	Spring Washer	4	69	075-0249	Carbon Brush	2
12	075-0206	Gear cover	1	70	075-0250	Brush Holder Ass	2
15	075-0207	Oil sealing washer	1	71	F-TFPX-4-9.5-ST-BZP	Screw ST2.9x9.5	4
16	F-CCINT-21-080-ST-PO	Circlip	1	72	075-0251	Rating Plate	1
17	075-0208	Safety Cover	1	73	075-0252	Name Plate	1
18	075-0209	Gasket	1	74A	075-0254	Switch 230V	1
19	075-0210	Spring 0.6x5x14	4	75	075-0255	Capacitor	1
20	075-0211	Slider Plate	1	76	075-0256	Left Handle	1
21	075-0212	Plunger Shaft	1	77	075-0257	Left Brush Cap	1
22	075-0213	Bushing	1	78	F-TFPX-6-13-ST-BO	Screw ST3.5x13	2
23	075-0214	Rubber Buffer	1	79	075-0258	Right Brush cap	1
24	075-0215	Top Bearing plate	1	80	F-TFPX-8-16-ST-BO	Screw ST4.2x16	4
25	075-0216	Steel Ball 2.5x6	2	81	F-TFPX-8-25-ST-BO	Screw ST4.2x25	1
26	075-0217	Blade release bearing	1	82	F-TFPX-8-38-ST-BO	Screw ST4.2x38	2
27	F-RW-M10-ST-BZP	Washer M10	2	83	075-0259	Right Handle	1
28	075-0218	Bottom Bearing Plate	1	84	075-0260	Cable Sleeve	1
29	F-SPHPZ-M5-12-ST-BZP	Screw M5x12	4	85A	075-0262	Cable & Plug 230V UK	1
30	F-CCEXT-8-025-ST-PO	Retaining ring 8	1	86	075-0263	Vacuum Adaptor	1
31	F-WB-M8-A2-SC	Washer M8	1	87	075-0264	Base Plate	1
32	075-0219	Needle Bearing	2	88	075-0265	Base adjusting block	1
33	075-0220	Bushing	1	89	F-SBHS-M6-15-ST-BZP	Button Head screw M6x15	1
34	075-0221	Drive Gear	1	90	075-0267	Anti Chipping plate	1
35	075-0222	Counter Weight	1	91	075-0268	Base Plate pad	1
36	075-0223	Fork Lever	1	92	F-SCHPZ-M4-8-ST-BZP	Screw M4x8	4
37	F-ECLIP-3-025-ST-PO	E-Clip	1	93	075-0269	Base Plate Shoe	1
38	075-0224	Roller Wheel	1	95	075-0270	Brush Springs	2
39	075-0225	Roller Pin	1	96	075-0271	Needle Bearing	1
40	075-0226	Roller Frame	1	97	075-0272	Parallel Guide	1
41	075-0227	Dust Air Deflector	1	99	F-HEXKEY-M4-ST-BO	4mm Hex Key	1
42	075-0228	Shim Washer	1	100	F-DP-4-18-ST-PO	Dowel Pins 4x18mm	2
43	F-TFPX-8-32-ST-BZP	Screw ST4.2x32	4	101	075-0274	Gear Shaft	1
44	F-DP-4-14-ST-PO	Dowel Pins 4x14mm	2	102	f-WB-M5-ST-BZP	Washer M5	1
45	075-0230	Pin 6x9.8	1	104	f-WB-M3-ST-BZP	Washer	2
46	F-ECLIP-4-025-ST-PO	E-clip 4	1	105	F-NSF-M4-ST-BZP	Nut M4	1
47	075-0231	Pin Roller Frame	1	106	075-0275	Spring	1
48	075-0232	Roller setting lever	1	107	F-CCEXT-10-090-ST-PO	Circlip 10	1
49	075-0233	Spring	1	108	075-0276	Sealing Block	1
50	075-0234	Steel Ball 4	1				
51	075-0235	Air deflector lever	1				
52	075-0236	Gear housing	1				
53	075-0237	Felt Seal	1				
54	075-0277	O-Ring	1				
55	F-B-609-2RSR	Bearing	1				
56A	075-0239	Armature 230V	1				
57	F-B-607-2RSR	Bearing	1				
58	075-0240	Bearing Sleeve	1				

Evolution Power Tools Ltd
 Venture One, Longacre Close, Holbrook Ind Estate, Sheffield, S20 3FR, UK
 Tel: +44 (0) 870 609 2297 Fax: +44 (0) 114 247 3339 www.evolutionpowertools.com

evolution
POWER TOOLS

RAGE 7S
Corded Jigsaw
075-0001.01

Service Parts List