



R185
CCS

Service Parts List	027-0004.01 - V3.8 Rev 2.05	120V USA
7-1/4" Multi-Material Cutting Circular Saw		

No.	Description	Part Code	Qty
1	Blade housing 185	027-0101	1
2	Blade Guard 185	027-0102	1
3	Motor housing Large	027-0103	1
4	End Cap (Orange)	027-0104	2
5	Main handle- LHS Blank (Orange)	027-0128	4
6	Main handle- RHS (Orange)	027-0106	4
7	Front Handle-LHS softgrip (Orange)	027-0107	2
8	Front Handle-RHS softgrip (Orange)	027-0108	2
9	Track Base	027-0109	5
10	Front bevel mount VP	027-0110	1
11	Rear bevel mount VP	027-0111	1
12	Bevel pivot plate (Cast Track 185)	027-0112	1
14	Arbour Lock Plate	027-0114	1
15	Fan baffle	027-0115	2
16	LED lens	027-0116	3
17	Depth Gauge- Cast Track (in)	027-0229	1
18	Dust Port Adaptor (185)	027-0118	1
19	Blade Guard bumper	027-0119	1
20	Blade guard lever (Orange)	027-0120	1
21	Adjustment lever (Orange)	027-0121	2
22	Cam adjustment knob (Orange)	027-0122	4
24	Gearbox Housing	027-0124	3
27	Armature 15A (USA 120V)	027-0132	2
28	Stator 15A (USA 120V)	027-0136	4
29	Switch Non-Lock off (Orange)	027-0125	1
31	Cable USA 120V (14AWG Rubber) 4m	027-0169	1
32	Cable Strain (Large)	027-0152	1
33	LED Transformer (100-120V)	027-0151	1
34	Flanged Blade Bolt	027-0158	1
36	Outer Flange (Machined A3)	027-0154	1
37	Inner Flange (20mm)	027-0155	2
37	Inner Flange (5/8in)	027-0156	5
38	Guard retention clip	027-0157	1
39	Screw ST 5X25	F-TFPX-5-25-ST-BO	9
40	Pan Head Screw M5x12	F-SPHPZ-M5-12-ST-BO	1
41	Guard Spring	027-0160	1
42	Bearing 6001 (C&U)	F-B-6001-2Z	1
43	Gearbox shaft	027-0162	2
44	Woodruf Key	027-0163	1
45	Circlip Internal 25mm	F-CCINT-25-120-ST-BO	1
46	Gear	027-0165	1
47	Needle Bearing	027-0166	1
48	Roll pin 6x40mm	F-SDH-600-40-ST-BO	1
49	Pan Head Screw M6x18	F-SPHPZ-M6-18-ST-BO	1
50	Coach bolt M6X21	F-CB-M6-21-ST-BO	1
51	Pan Head Screw M3x16	F-SPHPZ-M3-16-ST-BO	2
52	Arbour lock Spring	027-0171	2
53	Pan Head Screw M5x50	F-SPHPZ-M5-50-ST-BO	2
54	Screw ST 4X10	F-TFPX-4-10-ST-BO	1
56	Brush holder cap	027-0175	2
57	Carbon brush	027-0176	1
58	Brush holder	027-0178	1
59	Screw ST 4X16	F-TFPX-4-16-ST-BO	1
60	Terminal Block (4)	027-0177	2
61	LED unit	027-0180	1
62	Screw ST 4X8	F-TFPX-4-8-ST-BO	1
63	Screw ST 4X60	F-TFPX-4-60-ST-BO	1
64	Bearing 608 (C&U)	F-B-608-2Z	2
65	Bearing 6000 (C&U)	F-B-6000-2Z	1
66	Parallel guide	027-0185	2
67	Hex key M6 (6mm)	F-HEXKEY-M6-ST-BO	1
68	Pan Head Screw M5x30	F-SPHPZ-M5-30-ST-BO	4
69	Circlip External 16mm	F-CCEXT-16-100-ST-BO	2

No.	Description	Part Code	Qty
70	Cable Clamp	027-0189	4
72	E clip 9mm	F-ECLIP-9-100-ST-BO	1
73	Lever Hex Block	027-0192	1
74	Washer M6	F-W-M6-ST-BO	1
75	Pan Head Screw Allen M6X20	F-SBHS-M6-20-ST-BO	1
76	Hex Nut Half M6	F-NSH-M6-ST-BO	2
78	Socket head cap screw M6X12	F-SHCS-M6-12-ST-BO	1
80	Parallel Guide Thumb screw (Orange)	027-0199	1
81	Grub Screw M6X16	F-SSCCP-M6-16-ST-BO	1
85	Dust Hose Connector USA	027-0221	1
86	Terminal Block (2)	027-0244	1
87	Rubber Bearing Sleeve	027-0223	1
88	Wave Washer M6	F-WW-M6-ST-BO	1
91	Depth Lock Lever-Track (Orange)	027-0235	1
92	Rear Bevel Wing Knob- Track (Orange)	027-0237	1
94	Washer M4	F-W-M4-ST-BO	1
95	Rear Bevel Indicator (Orange)	027-0239	1
96	Rear bevel indicator screw	F-SPHPZ-M4-10-ST-BO	1
98	Thumb Screw Spring	027-0243	1
200	Armature Assembly (USA 120V)	027-0052	1
201	Gearbox Assembly	027-0060	1
205	60° Cast Base Assembly	027-0071	1

No.	Description	Part Code	Qty
-----	-------------	-----------	-----



Service Parts List	027-0004.01 - V3.8 Rev 2.05	120V USA
7-1/4" Multi-Material Cutting Circular Saw		