


R185
CCSX

Service Parts List	027-0002.01 - V3.8 Rev 2.01	110V
185mm Multi-Material Cutting Circular Saw		UK

No.	Description	Part Code	Qty
1	Blade housing 185	027-0101	1
2	Blade Guard 185	027-0102	1
3	Motor housing Large	027-0103	1
4	End Cap (Orange)	027-0104	1
5	Main handle- LHS Lock Off (Orange)	027-0105	1
6	Main handle- RHS (Orange)	027-0106	1
7	Front Handle-LHS softgrip (Orange)	027-0107	1
8	Front Handle-RHS softgrip (Orange)	027-0108	1
9	Track Base	027-0109	1
10	Front bevel mount VP	027-0110	1
11	Rear bevel mount VP	027-0111	1
12	Bevel pivot plate (Cast Track 185)	027-0112	1
14	Arbour Lock Plate	027-0114	1
15	Fan baffle	027-0115	1
16	LED Blanking plate	027-0127	1
17	Depth Gauge- Cast Track (mm)	027-0117	1
18	Dust Port Adaptor (185)	027-0118	1
19	Blade Guard bumper	027-0119	1
20	Blade guard lever (Orange)	027-0120	1
21	Adjustment lever (Orange)	027-0121	1
22	Cam adjustment knob (Orange)	027-0122	2
24	Gearbox Housing	027-0124	1
27	Armature 1600W (UK 110V)	027-0131	1
28	Stator 1600W (UK 110V)	027-0135	1
29	Switch Lock off (Orange)	027-0138	1
30	Capacitor (UK 110V)	027-0140	1
31	Cable UK 110V (2x1.5mm ² Rubber) 3m	027-0144	1
32	Cable Strain (Large)	027-0152	1
34	Flanged Blade Bolt	027-0158	1
36	Outer Flange (Machined A3)	027-0154	1
37	Inner Flange (20mm)	027-0155	1
38	Guard retention clip	027-0157	1
39	Screw ST 5X25	F-TFPX-5-25-ST-BO	1
40	Pan Head Screw M5x12	F-SPHPZ-M5-12-ST-BO	4
41	Guard Spring	027-0160	1
42	Bearing 6001 (C&U)	F-B-6001-2Z	1
43	Gearbox shaft	027-0162	1
44	Woodruf Key	027-0163	1
45	Circlip Internal 25mm	F-CCINT-25-120-ST-BO	1
46	Gear	027-0165	1
47	Needle Bearing	027-0166	1
48	Roll pin 6x40mm	F-SDH-600-40-ST-BO	1
49	Pan Head Screw M6x18	F-SPHPZ-M6-18-ST-BO	1
50	Coach bolt M6X21	F-CB-M6-21-ST-BO	2
51	Pan Head Screw M3x16	F-SPHPZ-M3-16-ST-BO	2
52	Arbour lock Spring	027-0171	1
53	Pan Head Screw M5x50	F-SPHPZ-M5-50-ST-BO	2
54	Screw ST 4X10	F-TFPX-4-10-ST-BO	3
56	Brush holder cap	027-0175	2
57	Carbon brush	027-0176	2
58	Brush holder	027-0178	2
59	Screw ST 4X16	F-TFPX-4-16-ST-BO	12
60	Terminal Block (4)	027-0177	1
62	Screw ST 4X8	F-TFPX-4-8-ST-BO	1
63	Screw ST 4X60	F-TFPX-4-60-ST-BO	2
64	Bearing 608 (C&U)	F-B-608-2Z	1
65	Bearing 6000 (C&U)	F-B-6000-2Z	1
66	Parallel guide	027-0185	1
67	Hex key M8 (6mm)	F-HEXKEY-M8-ST-BO	1
68	Pan Head Screw M5x30	F-SPHPZ-M5-30-ST-BO	1
69	Circlip External 16mm	F-CCEXT-16-100-ST-BO	1
70	Cable Clamp	027-0189	1
72	E clip 9mm	F-ECLIP-9-100-ST-BO	2

No.	Description	Part Code	Qty
73	Lever Hex Block	027-0192	2
74	Washer M6	F-W-M6-ST-BO	5
75	Pan Head Screw Allen M6X20	F-SBHS-M6-20-ST-BO	1
76	Hex Nut Half M6	F-NSH-M6-ST-BO	1
78	Socket head cap screw M6X12	F-SHCS-M6-12-ST-BO	2
80	Parallel Guide Thumb screw (Orange)	027-0199	1
81	Grub Screw M6X16	F-SSCCP-M6-16-ST-BO	3
85	Dust Hose Connector UK/EU	027-0220	1
87	Rubber Bearing Sleeve	027-0223	1
88	Wave Washer M6	F-WW-M6-ST-BO	2
91	Depth Lock Lever-Track (Orange)	027-0235	1
92	Rear Bevel Wing Knob- Track (Orange)	027-0237	1
94	Washer M4	F-W-M4-ST-BO	5
95	Rear Bevel Indicator (Orange)	027-0239	1
96	Rear bevel indicator screw	F-SPHPZ-M4-10-ST-BO	1
98	Thumb Screw Spring	027-0243	1
99	Hex key M6 (3mm)	F-HEXKEY-M6-ST-BO	1

No.	Description	Part Code	Qty
 evolutionpowertools.com			
Service Parts List		027-0002.01 - V3.8 Rev 2.01	
185mm Multi-Material Cutting Circular Saw			110V UK